


DISASSEMBLY ON ARRIVAL Eazi Fount Canlines LTD +44 151 420 7000 www.canlines.co.uk


## Unit Type: CD2

This guide is also downloadable at www.canlines.co.uk/eazi-fount-info




Loosen this screw to remove the chamber.








Loosen these screws to remove the tube assembly from its support.







## ADJUSTING YOUR CHAMBER

Eazi Fount


Canlines LTD +44 151 420 7000 www.canlines.co.uk

Unit Type: CD2




These screws act as a lock when in operation to prevent chamber movement when printer trips.





These bolts adjust the top and bottom blades to the roller.





Turning these will adjust the parallelism of the chamber to the roller.





These bolts adjust the horizontal tilt angle to keep the chamber parallel.





## This bolt adjusts the blade pressure to the roller.

